

NPA De-Energisation:

De-Energisation Successfully Completed on First Visit to Site.

Supervisor Actions

- Schedule job for action and completion within 5 days of receiving service order.

Network Technician Actions

- Contact ACO by phone from site to update.
- Leave letter at premises. (*Use letter for "Process 1"*)
- Finish the call in Areas on same day, giving details of meter readings.
- Return CX (with MPRN status showing de-energised) to Database within 24 hours.

ACO Actions

- Take phone call from NT on site giving details on status of job.
- E-mail Supplier using standard template (N.P.A. De-Energisation Action Report) immediately after phone call is received from NT.
Email should include 3 numbers: (i) MPRN (ii) Networks' Service Order No.
(iii) Supplier's Purchase Order No.

Process 1 - NPA De-energisation where Networks completes De-Energisation on the first visit

