





343 SMART Import Interval Meter Daily Readings


341 Valid Codes
Register Type
50 Import QH (Kw)
51 Import QH (kVAr)
52 Export QH (Kw)
53 Export QH (kVAr)
Unit of Measurements
KWT = kW
KVR = KVAR
Alert Flag (previously called Channel Status in v 6.1)
VV – all values are valid
VI – values are invalid. Typically this will be due to non-zero values on a de-energised site
Interval Status
VEST – indicates that the value is estimated
VCHG – indicates a value that has been manually changed by MRSO
VACH – indicates a value that has been manually changed (substituted) by PDS
VVAK – indicates that the value is collected or totalised from a meter
Optional/Mandatory; Although the following Data Items are optional, note the following caveats:-
Generator ID: Provided for export sites
Generation Unit ID: Provided for export sites
Value (Net Active Demand): Provided for import channels on export sites where netting occurs
. Unit of Measurements: KWT = kW
KVR = KVAR















343 SMART Import Interval Meter Daily Readings

Code



Message

MPRN Level Information

RMDS RETAIL MARKET DESIGN SERVICE

Alert Flag

Meter Category

**Click Here for Latest
Meter Category
List**

343 SMART Import Interval Meter Daily Readings

Code

Register Type

70 - Import HH kW

Message


Channel Info


RMDS RETAIL MARKET DESIGN SERVICE

Register Type

343 SMART Import Interval Meter Daily Readings

Code





343 SMART Import Interval Meter Daily Readings

Version Which Implemented	Source of Change	Description of Change
13.00	V 13.00 Smart Changes	New Market Message for Smart